



Tankningsinstruktion

Refueling instruction

Ta på skyddsutrustning innan tankning

Put on safety equipment before refueling



**Ögonskydd
måste användas**



**Skyddshandskar
måste användas**



**Heltäckande kläder
måste användas**

Tankningsinstruktion



1. Dra ditt betalkort i betalterminalen.
2. Anslut:
 1. Jordkabel
 2. Tankningsmunstycket (blås rent tankningsmunstycket och fordonets koppling ORDENTLIGT innan anslutning)
 3. Munstycke för avluftning (gäller inte Volvo)
3. Öppna fordonets ventil för avluftning
4. På dispenserns display: → Välj fordonstyp (Volvo "Kall" eller Scania, Iveco "Varm").
5. När den gröna knappen visas på dispensers display: → Tryck en gång på den gröna knappen på dispensern.
6. Titta på dispenserns display. När sekvensen för avluftning är avslutad och sekvensen för nedkylning av dispensern påbörjats: → Stäng fordonets ventil för avluftning.
7. Titta på dispenserns display. När sekvensen för nedkylning är avslutad och den gröna knappen visas på displayen: → Tryck på den gröna knappen på dispensern.

Tankningen startar. Håll den gröna knappen intryckt under hela tankningen.
8. När tankningen är avslutad. Koppla loss samtliga munstycken och jordkabeln.

Refueling instruction



1. Insert your card in the payment terminal.
2. Connect:
 1. Earthing cable
 2. Refueling nozzle (clean the refueling nozzle and the filling connection on the vehicle with the air gun)
 3. Nozzle for evacuation (not applicable for Volvo)
3. Open the venting valve on the vehicle.
4. On the dispenser display: → Choose type of vehicle (Volvo "Cold" or Scania, Iveco "Warm").
5. When a green button is shown on the dispenser display: → Press once on the green button on the dispenser.
6. Look at the dispenser display. When the sequence for venting is ended and the sequence for cooling down the dispenser has started: → Close the venting valve on the vehicle.
7. Look at the dispenser display. When the sequence for cooling down the dispenser has ended and a green button is shown on the dispenser display: → Press the green button on the dispenser.

Refueling starts. Continue to press the green button until the refueling has ended.

8. When the refueling has ended. Disconnect all nozzles and the earthing cable.